

## How to Connect and Download

ElcoMaster is the complete data management solution for coating inspection, allowing you to transform your inspection data into professional reports in minutes.

With ElcoMaster, connecting your Elcometer gauge is quicker and easier than ever before.

Depending on the gauge you are using, connecting your gauge can be done either by USB or Bluetooth.

Simply open up ElcoMaster and select *Download Measurements* from the home screen, here you will be given the option to select an existing project or create a new one.

If you are creating a new project, you must now enter the name of the project as well as any project and batch labels, if desired.

Next, press *Select* on the *Measurements* tab of the project you wish to save the data to.

You will then be asked to select the gauge you wish to download data from. The screen will show any Bluetooth-enabled gauges that are within range or connected to the PC you are using via USB.

Once the gauge is connected, you can choose which batches to download from the gauge. Tick all the relevant batches and press 'Download'.

You will then see the downloaded batches on the left hand side of the screen under *Measurements*.

Click on the batches to view the readings and information.

For more information on ElcoMaster, visit [www.elcometer.com/elcomaster](http://www.elcometer.com/elcomaster) or search 'ElcoMaster' in the App Store or Google Play to download now.